



Hanging Your Magnetic Knife Board

Our Magnetic Knife Boards have keyholes on the back for hanging in drywall. On the small boards, the keyholes are 10" inches apart on center. On the medium and large boards, the keyholes are 16" apart on center. The keyholes on all boards are 1" down from the top of the board. We include two bear claw screws for hanging your board.

Bear claw screws are double-headed anchorless screws that fit into the keyholes to hang your board tightly and flush against the wall. These screws are self-drilling and do not require any drywall anchors and still hold up to 30 lbs. in drywall and 100 lbs. in studs which is more than enough to securely hold the boards as well as your knives. This applies to drywall. If you have tile, please consult a professional with the proper tools for drilling through tile.

Simply install the screws 10 or 16 inches apart depending on the size of your board until the first head is flush with the wall. Line the wide opening of the keyholes on the board up so the second head slips into the keyhole and then pull down slightly so the head slides into the narrow opening to securely anchor your board. If the board is not snug against the wall the screws need to be set slightly deeper. If the screws do not slide up into the narrow portion of the keyhole they need to be loosened.

Thank You,

Heather and Billy
B Squared Woodworking, LLC
(844) 277-9663
<https://bsquaredwoodworking.com>